



## Assembly Instruction For 10003

1. Attach the crystal shades ( B ) to the sockets ( A ) then secure by socket rings ( C ).
2. Install the bulbs ( D ) to the sockets ( A ).

