

1. Spread the arms evenly, make sure each arm is aligned with the center rod.
2. Slide the loop set and cap down the wire until it touches the round plate, turn the loop set into the coupler.
3. Install the glass according to the drawing.
4. Refer to the installation instructions attached for wiring instructions.

