

1. Put the tube 2 on the cap, then place the nipple through tube 2 into coupler till tighten;
2. Place the tube 3 and shade on the socket.

