



Assembly Instruction For 12764

Attach the shade and the cap to the socket then secure by socket ring.

