

Parts Breakdown

Pressure Balance Tub And Shower Faucet Valve With Stop



PF4001



PF4001

Part Name

No.	Item	Part Number
1	Plaster guard	ACF4001GRD
2	Bonnet	RP70616
3	Cartridge	ACF4001UCRT
4	Stop valve	ACF4001STOP
5	O-ring	RP60122
6	Plug(For PF4001F)	RP70153
7	Plug(For all the other)	RP70365

