

Models/Modelos/Modèles
9190-DST & 9190T-DST
 Series/Series/Seria
BRODERICK™

RP100845▲

Escutcheon, Mounting Screws (2), Gasket, Nuts (2) & Washers (2) (not included)
 Chapa, tornillos de montaje (2), empaque, tuercas (2) y arandelas (2) (no se incluyen)
 Plaque de finition, vis de montage (2), joint, écrous (2) et rondelles (2) (non inclus)

RP80977

Wand Retainer & Replacement Kit
 Soporte para el mango y piezas de repuesto
 Trousse de Rechange et pièce de Retenue de Douchette

RP100833▲

Sprayer Assembly
 Ensemble de Rociador
 Pulvérisateur

RP100832

Gasket
 Empaque
 Joint

RP80523

Steel Weight Assembly
 Ensemble de la Pesa de Acero
 Masselotte en acier

RP6092

Nuts (2) & Washers (2)
 Tuercas (2) y Arandelas (2)
 Écrous (2) et rondelles (2)

RP60911

Clip
 Presilla
 Agrafe

RP73984

O-Ring & Clip
 Anillo y Presilla
 Joint torique et Agrafe

RP80522

Hose Assembly
 Ensemble de la manguera
 Tuyau souple

RP100829▲

Spout
 Canalón
 Bec

RP60923

Retainer
 Funda
 Douille

RP91902

Cartridge Assembly
 Ensemble del la Válvula
 Soupape

RP100336▲

Cap & O-Ring
 Bonete y Anillo O
 Chapeau et Joint toriques

RP78741

Contact
 Spring
 Resorte de Contacto
 Ressort de contact

RP74776

Bonnet Nut
 Tuercas
 Écrou

RP100835▲

Set Screw & Button
 Tornillo de Ajuste y botón
 Vis de calage et bouton

RP92605

Indicator Base Assembly
 Ensemble de la base con indicador
 Base à voyant indicateur

RP13938

O-Rings (2)
 Anillos "O" (2)
 Joints torique (2)

RP100834▲

Handle, Set Screw & Button
 Manija, tornillo de presión y Botón
 Poignée, vis de calage et bouton

RP51243

Inlet Gaskets
 Empaques para el tubo de entrada
 Joints côté alimentation

RP92714

Mounting Bracket Assembly, Spacer, Nut & Wrench
 Ensemble del soporte de montaje, Espaciador, la tuercas y la llave de tuercas
 Fixation de montage, spacer, écrou et clé

▲Specify Finish/Especifique el Acabado/Précisez le Fini


Models/Modelos/Modèles
9190-DST & 9190T-DST
 Series/Series/Seria
BRODERICK™

EP92546
 Solenoid Assembly
 Ensemble de Solenoïde
 Électrovanne


For PC, SS, AR & KS finishes, order **EP92546**
 For PL, MW, RB & SP finishes, order **EP92546**

Para acabados PC, SS, AR y KS, ordene **EP92546**
 Para acabados PL, MW, RB y SP, ordene **EP92546**


Pour les finis PC, SS, AR et KS, commandez **EP92546**
 Pour les finis PL, MW, RB et SP, commandez **EP92546**




EP73954
 9 Volt Power Supply
 (Accessory Order Only)
 Fuente de alimentación de 9 voltios
 (Orden de accesorios solamente)
 Alimentation électrique 9 volts
 (L'accessoire seulement)





RP37490
 Thin Deck Aid (Not Included)
 Soporte para encimera delgada
 (No incluido)
 Plaque de renfort (non incluse)



RP83779
 Pump
 Bomba
 Pompe



RP100632
 Dispenser Assembly
 (Not included)
 Ensemble del Dispensador (no se incluyen)
 Distributeur (non inclus)




RP53468
 Check Valves
 Válvulas
 Checadoras
 Clapets de non-retour



RP78489
 Nut
 Tuerca
 Ecrou



RP78490
 Bottle
 Botella
 Bouteille



RP93410
 Filter
 Filtro
 Filtre

RP13938
 O-Ring (2)
 Anillo "O" (2)
 Joint torique (2)




RP60911
 Clip
 Presilla
 Agrafe


RP78389
 Battery Box
 Caja de la Batería
 Boîtier de piles

Other useful accessories that may be purchased separately.
 Otros accesorios útiles que se pueden comprar por separado.
 Autres accessoires utiles pouvant être achetés séparément.

RP63263
 Adapters
 3/8"-24 UNEF to 1/2"-20 UN &
 3/8"-24 UNEF to 1/2"-14 NPSM
 Adaptadors
 3/8"-24 UNEF a 1/2"-20 UN &
 3/8"-24 UNEF a 1/2"-14 NPSM
 Adapteurs
 3/8 po-24 UNEF à 1/2 po-20 UN et
 3/8 po-24 UNEF à 1/2 po-14 NPSM



RP63264
 Adapters (10) 3/8"-24 UNEF to 1/2"-20 UN
 Adaptadors (10) 3/8"-24 UNEF a 1/2"-20 UN
 Adapteurs (10) 3/8 po-24 UNEF à 1/2 po-20 UN



RP63265
 Adapters (10) 3/8"-24 UNEF to 1/2"-14 NPSM
 Adaptadors (10) 3/8"-24 UNEF a 1/2"-14 NPSM
 Adapteurs (10) 3/8 po-24 UNEF à 1/2 po-14 NPSM

