



Model/Modelo/Modèle
5COM09-PAC, 5COM12-PAC,
5COM15-PAC, 5COM18-PAC &
5COM24-PAC





EP103170 - 9kW 208V 1PH
EP103171 - 9kW 208V 3PH
EP103172 - 9kW 240V 1PH
EP103173 - 9kW 240V 3PH
EP103174 - 9kW 480V 3PH

EP103175 - 12kW 208V 1PH
EP103176 - 12kW 208V 3PH
EP103177 - 12kW 240V 1PH
EP103178 - 12kW 240V 3PH
EP103179 - 12kW 480V 3PH


EP103180 - 15kW 208V 1PH
EP103181 - 15kW 208V 3PH
EP103182 - 15kW 240V 1PH
EP103183 - 15kW 240V 3PH
EP103184 - 15kW 480V 3PH

EP103228 - 18kW 208V 1PH
EP103185 - 18kW 208V 3PH
****EP103186** - 18kW 208V 3PH
EP103187 - 18kW 240V 1PH
EP103188 - 18kW 240V 3PH
EP103189 - 18kW 480V 3PH

EP103190 - 24kW 208V 3PH
****EP103191** - 24kW 208V 1PH
EP103192 - 24kW 240V 3PH
****EP103193** - 24kW 240V 1PH
EP103194 - 24kW 480V 3PH

EP103195 - 30kW 208V 3PH
EP103196 - 30kW 240V 3PH
EP103197 - 30kW 480V 3PH

EP103198 - 36kW 208V 3PH
EP103199 - 36kW 240V 3PH
EP103200 - 36kW 480V 3PH



EP103522 - 3kW 120V 1PH
EP103521 - 4kW 208V 1PH

EP103512 - 7.5kW 240V 1PH
EP103513 - 7.5kW 240V 3PH
EP103523 - 7.5kW 208V 3PH


EP103527 - 9kW 220V 3PH
EP103524 - 9kW 208V 1PH
EP103525 - 9kW 208V 3PH
EP103526 - 9kW 240V 1PH

EP103528 - 12kW 208V 3PH

EP103529 - 15kW 208V 1PH
EP103530 - 15kW 208V 3PH

EP103531 - 18kW 208V 3PH
****EP103532** - 18kW 208V 3PH

EP103533 - 24kW 480V 3PH



EP103224
Auxiliary Reset
Restablecimiento auxiliar
Réinitialisation auxiliaire

** For 5COM models with serial numbers 40000 and above only.
 ** Solo para modelos 5COM con números de serie 40000 y superiores.
 ** Pour les modèles 5COM portant les numéros de série 40000 et supérieurs uniquement.