GENERATION LIGHTING

PENDANT

GENERAL PRODUCT INFORMATION:

These fixtures are intended to be installed utilizing NEC compliant junction boxes.

This product is safety listed for damp locations.

Incandescent version may be dimmed with a standard incandescent dimmer. LED version may be dimmed with a LED dimmer. Consult lamp manufacturer for additional information.

This instruction shows a typical installation.

SAVE THESE INSTRUCTIONS!


CAUTION - RISK OF FIRE

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Use minimum 90°C supply conductors.



Install the Fixture



- Determine the wanted height or look of the fixture with the provided hang straight (or link and loop and stems), then assemble by screwing them together. NOTE: Use hang straight for standard ceilings and use link and loop for sloped ceilings.
- 2 Feed the fixture wires through the stem/chain assembly and screw the assembly onto the socket.
- 3 Unscrew the collar nut off the screw collar and place it onto the stem/chain followed by the canopy.
- 4 If necessary, screw the threaded nipple tightly onto the mounting plate.
- 5 Feed the fixture wires through the threaded nipple and screw the mounting plate assembly onto the stem/chain assembly.
- 6 Align and secure the mounting plate to the junction box.
- 7 Connect the fixture to a suitable ground in accordance to local electrical codes.
- 8 Connect the white fixture wire (square and/or rigid) to the neutral power line wire with a wire nut.
- 9 Connect the black fixture wire (round and/or smooth) to the hot power line wire with a wire nut.
- Neatly place all the wires into the junction box, place the canopy onto the ceiling, and secure it in place by screwing the collar nut tightly into the screw collar.
- Lift he shade lip onto the frame and secure in place using the shade screws.
- Screw the lamp into the socket. Refer to the label on the socket for Max Wattage Information.